



Cabinet doors get caught,
doesn't close





Cabinet doors are misaligned. Loose by the hinges.

